


Performance Volt Gauge

Amber/White Display (270° Scale)



Wiring Instructions

Red- 12v accessory Power (+)


Black- Ground negative (-)

White- Engine Accessory power

Orange-Parking lamp. Meaning a power source that has 12v power when parking lights are turned on.

Lighting Diagram

<i>Day Time</i>	<i>Night Time</i>	
White	White	White — Connect to acc. Power Amber — Do not connect
Amber	Amber	White — Do not connect Amber — Connect to acc. Power
White	Amber	White — Connect to acc. Power Amber — Connect to parking lamp
Amber	White	White — Connect to acc. Power Amber — Connect to parking lamp



Do not over tighten bolts when installing U bracket. Doing so will cause damage to movement inside.