

ELECTRICAL GAUGES W/PEAK & WARNING

52mm SUPREME SERIES WHITE / AMBER LED DISPLAY

Fuel Press Gauge

OPENING CEREMONY

**1**

**BACK VIEW**

Red - Battery (+)  
Black - Battery (-)  
White - Ignition Switch +12V  
Orange - Dash Lighting

**2**

Gauge pod mounting screw

Meter mount

Peak LED Blue

Warning LED Red

**3**

Double-Sided-Type Cord

\*\*Warning light sold separately

External Warning Light

Warning Light Wire Harness

**5**

RED BLACK WHITE

1/8 NPT THREAD

PRESS SENSOR

**6**

Fuel pressure regulator

Wind toflon tape

Hose union (commercially available)

Three-way joint (commercially available)

Fit tightly with clamps (commercially available)

Fuel return pipe (low pressure)

Fuel feed pipe (high pressure)

To sensor wire

sensor

Be sure not to twist

\*Cut the fuel feed pipe and install hose unions.

**7**

CONNECTOR FOR SENSOR WIRE

SENSOR WIRE

BLACK CONNECTOR

FUEL PRESS SENSOR

Exhaust Gas Temperature Gauge

OPENING CEREMONY

**1**

**BACK VIEW**

Red - Battery (+)  
Black - Battery (-)  
White - Ignition Switch +12V  
Orange - Dash Lighting

**2**

Gauge pod mounting screw

Meter mount

Peak LED Blue

Warning LED Red

**3**

Double-Sided-Type Cord

\*\*Warning light sold separately

External Warning Light

Warning Light Wire Harness

**4**

EXHAUST GAS TEMP SENSOR

M6 x P1.25 Thread

1/8 PT Thread

Bushing Nut

Exhaust pipe

**5**

Exhaust Manifold

Drill a hole  
On either position  
And installing the  
1/8PT thread jointer

**6**

CONNECTOR FOR SENSOR WIRE

SENSOR WIRE

YELLOW CONNECTOR

EGT Sensor